

HIGH CAPACITY BATTERY (HCB)



The High Capacity Battery (HCB) replaces the existing battery and significantly increases the performance of your power ascender. The ascent and descent speed of the machine remains the same as before.

1. Increased Lifting Range – 3 times more distance with HCB (Up to 600m with 100kg load).
2. A fully charged HCB battery is now able to lower the WLL of the Ascender up to 100m as a standard procedure. If a greater lowering distance is required, then the battery charge level should be reduced to 75% charge or less.
3. If using the High Capacity Battery (HCB) then the HCB Charger must be used.

CHARGER FOR HCB



The HCB charging time is 90 mins for an empty battery. The Battery Care and Handling Guidelines remain unchanged.

1. Only the original battery and original charger (pictured LEFT) will work together.
2. Only the HCB battery and HCB charger (pictured RIGHT) will work together.
3. The original ActSafe Battery will not work with the HCB Charger.



Note

Ensure the correct charger is used.